


External connection diagram



Clarifications:

16-pole contact: See connectionbox CBD.

JP2 [DIN1]

Closed: Pull-Up ON [+5V]. Open: Pull-Up OFF.

JP1 [Terminering]

Closed: CAN terminerad